GMCC ASG300N1UMT

GMCC 1. Application

A/C Type	Cooling & Heating A/C System
Refrigerant Type	R410A
Maximal Refrigerant Charged	1.8 Kg Max
Power Source	Single Phase 1φ-208-230V-60Hz
Safety Approval	UL

2. Specification

Compressor Type	Hermetic Motor Compressor		
Displacement	30.0 cm ³ /rev.		
Oil Charged	ESTER OIL VG74·560 ·ml ±15 ·ml		
Weight (Oil Included)	19.45 Kg ±3% Kg		
I.D. of Discharge Pipe	φ9.8 ±0.1mm		
I.D. of Suction Pipe	φ16.2 ^{+0.2} _{-0.1} mm		

3. Motor Specification


Motor Type	Single Phase Induction Motor PSC	
Pole Numbers	2 Poles	
Insulation Grade	E Grade	
Coil Resistance(at 68°F)	Main: 0.91 ±5%Ω Aux.: 1.17 ±5%Ω	
Locked Rotor Amps	at 1 ф -240V-60Hz 72 ±10% А	
Ruing Capacitor	60μF ≥400V	

GMCC ASG300N1UMT

4. Rated Performance Parameters

Rated Capacity	8910/8945	±3% W	30,521 BTU
Rated Input Power	2820/2850	±3% W	
Rated Input Current	13.70/12.70	±3% A	
COP(*Remarks) %	316/314	±3%	
NOISE dB(A) (Sound Power Level)	★ 81	MAX	
VIBRATION	★ 20	MAX	


5. Wire Connection Figure



S: START (Aux Winding) R: RUN (Main Widing)

C: COMMON

RC: Run Capacitor




6. Application Notice

- 1. When design the connection tube, the system should be consider the vibration stress at the compressor start, stop and the system transportation status, ensure it doesn't be damaged. The recommendation value of the connection tube stress is below 34.3N/mm2 at the start, stop status and below 19.6N/mm2 at the running status.
- 2. Do not put a compressor on its side or turn it over. And do not fall it off when moving.
- 3. Compressing air is not permitted.
- 4. Please Assemble the Compressor in Your Air Conditioner Rapidly after Removing the Plugs. Do not leave the compressor for more than 10 minutes without plug.
- 5. Please use the accessories indicated by Our Company.

GMCC ASG300N1UMT

6. When the amount of refrigerant charged in the Air Conditioner is over the max amount allowable, compressor specification should be discussed. (Install additional accumulator, oil heater, etc.)

- 7. Refrigerant must always be filled from the higher side of the refrigeration cycle.
- 8. Avoiding compressor running in reverse caused by connecting electrical wire incorrectly. (Don't reuse the compressor after running in reverse.)
- 9. The compressor should be kept out of storing in open storage or corrosive atmosphere such as in a chemicals storage and so on.
- 10. Do not allow electric cables or the like to touch compressor directly.
- 11. To avoid water droplets and dust into the compressor, moisture-proof or dust-proof measures must be take.
- 12. For split type Air Conditioner, the maximum piping length should be 15m, and elevation difference should be within 5m.
- 13. Do not fill refrigeration cycles with other refrigerant except R32.
- 14. Do not touch the compressor with bare hands during operation or immediately after stoppage. The compressor is at a high temperature. There is the danger of burns.
- 15. Wear safety goggles when servicing the unit. When removing the tubes by heating it with a burner, there is the danger of burns or eye injury if the refrigerant and/or oil remaining in the tubes is emitted.
- 16. Below warning must be written into maintenance and user manual of whole unit: WARNING:
 - • When recharge the refrigerant, the processing must be done by the manufacturer or manufacturer appointed repair shop or service agent because correct type of refrigerant must be ensured.
 - - Prohibition of mixing the refrigerants.
- 17. Do not remove the terminal cover when welding the discharge pipe and a heat shield is required to protect the terminal cover from the impact of welding heat



(COMPRESSOR DRAWING)

